




### USER'S MANUAL

SOFTWARE VERSION 7.0  
code 80384A / Edition 0.2 - 05/04

## 1 • INSTALLATION

### • Dimensions and cut-out



#### Panel mounting.

Front panel dimensions: 96x96 mm./3.78"x3.78" (1/4DIN); depth:159 mm /6.26"

Cut-out dimensions: 92 (+0.8/-0)x92 (+0.8/0) mm/3.62" (+0.03/-0)x3.62" (+0.03/-0)".

To lock the instrument, insert the two blocks into the dovetail guides diagonally to one another and tighten with the screws. To install two or more instruments side by side or stacked, use the locking blocks and the following hole measurements:

**side by side** - Base (96 x n)-4 / (3.78 x n)-0.15" Height 92 (+0.8/-0) / 3.62" (+0.03/-0)

**column** - Base 92 (+0.8/-0) / 3.62" (+0.03/-0) Height (96 x n)-4 / (3.78" x n)-0.15" where "n" is the number of instruments.

**CE MARKING:** EMC (electromagnetic compatibility) conformity to EEC Directive 89/336 with reference to generic standards CEI-EN61000-6-2 (immunity in industrial environment) and EN50081-1 (emission in residential environment).

BT (low voltage) conformity to EEC Directive 73/23 modified by Directive 93/68.

**MAINTENANCE:** Repairs may be done only by trained and specialized personnel. Cut power to the instrument before accessing internal parts. Do not clean the case with hydrocarbon-based solvents (trichloroethylene, gasoline, etc.). The use of such solvents will compromise the instrument's mechanical reliability. Use a clean cloth moistened with ethyl alcohol or water to clean external plastic part.

**TECHNICAL SERVICE:** GEF 2301 has a technical service department.

Defects deriving from any use not conforming to this manual are excluded from the warranty.



For correct installation, follow the instructions contained in this manual

## 2 • TECHNICAL SPECIFICATIONS

### INPUTS

Precision 0,2% f.s. ± 1 digit. Sampling time 2msec

#### Strain-gauge

350Ω (for pressure, force, etc.), sensitivity 1,5/2/2,5/3/3,3mV/V, polarization: positive, symmetrical, negative.

**Potentiometer** > 350Ω, Ri > 10 MΩ

#### DC - Linear

0...50mV/ -25...25mV/ -50...0mV/ 0...60mV/ -30...30mV/ -60...0mV/ 0...100mV/ -50...50mV/ -100...0mV/ 0...1V/ -500...500mV/ -1V...0V/ 0...10V / -5...5V / -10V...0V

For all inputs in voltage Ri > 1MΩ / 0...20mA, 4...20mA, Ri = 50Ω. 32-section custom linearization available.

#### Auxiliary inputs

Two remote analog trip setpoints, absolute or relative to local set. 0...10V, Ri> 1MΩ / 0...20mA, Ri = 50Ω / 4...20mA, Ri = 50Ω

#### Digital

Optically isolated 1500V. 2 inputs with configurable function: reset trip memory, reset peak memory, check calibration, enable remote setpoints, Hold function.

- NPN or PNP 24V/4mA

## 2 • TECHNICAL SPECIFICATIONS

### OUTPUTS

#### **Continuous**

MAIN analog control in voltage or DC

1500V isolation

0...10Vdc, -5...5Vdc, -10...10Vdc Rload > 500Ω short-circuit protection 0...20mA, 4...20mA, Rmax = 500Ω

#### **Relay**

With 5A/250Vac contacts at  $\cos\phi = 1$  (3,5A at  $\cos\phi = 0,4$ ). Spark suppression on NO contacts.

#### **Logic**

In voltage for static relay control (SSR) 23Vdc, Rout = 470Ω (20mA, max. 12V).

#### **Retransmission**

1500V isolation.

Retransmission output for input, peak values, remote sets, direct and inverse control output, positive or negative deviation, alarm setpoint, configurable scale (minimum and maximum) settable from panel keys.

0..10Vdc; Rload > 500Ω / 0...20mA, 4...20mA Rmax = 500Ω Resolution 4000 points. Response time 8 msec.

#### **SERIAL LINE**

Optically isolated 4 wires.

The instrument is available with Current Loop (1200 baud) or RS485 4-wire (1200...9600 baud). Protocol: GEFAN CENCAL or MODBUS

#### **SENSOR SUPPLY**

1500V isolation.

5, 10 or 15Vdc...200mA or 24Vdc...100mA

#### **POWER SUPPLY**

100...240Vac  $\pm 10\%$  / 11...27Vac/dc  $\pm 10\%$  / 50...60Hz; 15VA max. Protected by internal fuse not serviceable by user

#### **AMBIENT CONDITIONS**

**Working temperature:** 0...50°C

**Temperatura di stoccaggio:** -20...70°C

**Storage temperature:** 20...85%Ur non-condensing

#### **CONTROLLER**

Self-adaptive PI or PID control with calculation time every 20 msec.

iAutomatic/manual function with bumpless function to prevent disturbance on return to auto mode after period of manual process control. Auto or manual status programmable at power-on. Ramp can be set for switch from current setpoint to new setpoint.

Gradient can be defined for power update (calculated from control algorithm). Digital filter programmable on input signal; digital filter programmable on process variable display. Saving of max peak, min peak, max-min peak value of input signal retrievable by means of panel button and LED signal.

#### **ALARMS**

- 2 alarm setpoints settable in absolute or deviation value with functions completely configurable from panel keys (Direct / Reverse / Deviation / Symmetrical Deviation)

- Setting of trip point along entire selected scale.

- Trip hysteresis settable from panel keys.

- Function: minimum or maximum trip points with saving of trip (LATCH) selectable during configuration.

Assigned to process variable or to setpoint. Relays energized or de-energized in trip status: selected from panel keys.

Trip can be excluded during power-up phase until input variable exceeds set trip point. Relay trips when variable drops below trip point.

Output activation can be timed.

iTrip response time:

for AL1 and AL2 = 2 msec

#### **WEIGHT**

700g

### 3 • DESCRIPTION OF FACEPLATE

#### A Display

\* Value of controlled variable resolution 4000 points in range - 1999/+9999, selectable decimal point, off-scale (-HI-) or (Lo) signal; indication of broken Strain Gauge probe:

**E\_br**: probe energizing interrupted

**H.sbr**: wire + interrupted

**L.sbr**: wire - interrupted

#### B Display

Displays settings, setpoint, trip points, remote setpoints. Data is presented as messages on display C or as status of LEDs M. Under normal work conditions, displays selected setpoint (local or remote).

#### C Display

Displays messages during configuration and power level 0/100.0%.

Power is displayed during normal operation, and can be changed with keys or by remote input in manual mode (MAN LED flashing).

#### D Display

Bargraph 0/100%. Graphic display of power as percentage.

#### N Display

Bargraph  $\pm 10\%$ . Graphic display of deviation value as percentage.

#### M Display

Signal LEDs:

**MAN** MAN indicates Manual controller state. When flashing, indicates that power may be varied with Raise and Lower keys.

**REM** signals that remote setpoint (absolute or deviation) is on.

**CAL** signals calibration control by probes or transmitters.

**AL1/AL2** flashing signals indicating display of trip points. If on, indicates that relay is energized.

#### CONTROLS

##### E "F" Function button

Accesses value display and/or setting functions. If button **F** is not pushed to confirm a setpoint change, it will be saved automatically after 10 seconds. Use button **F** to confirm the set value. Keep button **F** pressed to access the various configuration and calibration phases. By simultaneously pressing key **F** and the Raise and Lower buttons, you can enter the calibration menu even with protection S4 OFF.

##### F / G Raise and Lower Buttons

Let you increase or decrease displayed value for setting data or selecting an option. During calibration of repetition output or control output, the Raise/Lower keys let you change the minimum and maximum value. Increase/decrease speed is proportional to the time the key is kept pressed. The procedure is not cyclical: when the maximum (minimum) for the field is reached, the function stops even if the key is pressed. During manual function, the keys let you change the power level.



##### H "MAN/AUTO" button

Configurable function (see CFG2 butt.3 parameter):

- automatic calibration control for pressure probes or transmitters (◆)
- reset trip memory
- reset peak memory (◆◆)
- enable remote set 1 and/or 2
- select Manual/Automatic
- **HOLD** function for sampled input value

##### I "CAL/RST" button

Configurable function (see CFG2 butt.2 parameter):

- automatic calibration control for pressure probes or transmitters (◆)
- reset trip memory
- reset peak memory (◆◆)
- enable remote set 1 and/or 2
- select Manual/Automatic
- **HOLD** function for sampled input value

##### L "PEAK" button

Pressing the **Peak** button displays the peak value, i.e., the data shown on display **B** corresponds (depending on the type of peak selected) to (see CGF2 butt.1 parameter):

- "peak +" maximum value reached by variable
- "peak -" minimum value reached by variable
- "peak - peak" difference between "peak +" and "peak -"

Press key **F** to exit.

The instrument resumes display of the process variable. Peak memory remains active internally, and can be displayed at any time.

(◆)The calibration control function provides a known calibration signal from the unstressed transducer. In this condition, alarm relay status and the value of the analog input repetition signal are unchanged. The calibration function is signaled by lighting of the LED on the front panel (CAL).

(◆◆) When the peak memory reset function is enabled, the button updates the peak memory to the current value of the input signal. These functions are also available by means of configurable external contacts (see "Electrical connections" and "Configuration CFG2: d.i.F.1 and d.i.F.2).

## 4 • CONNECTIONS

See the Appendix to the manual for the electrical diagrams.

## 5 • ELECTRICAL CONNECTIONS

The instrument consists of 2 basic boards and has 44 terminals divided into 2 section (A and B).

### Signal inputs

Signal inputs from pressure probes and signals in direct voltage and in direct current 0-20mA, 4-20mA use terminals A1 (+) and A2 (-).

For the potentiometer input, the max end must be connected to terminal B20 (+Exc), the min end to terminals A2 and A3 (-), the cursor to terminal A1 (+).

### Remote setpoint inputs

The 0-10V, 0-20mA, 4-20mA inputs for any remote set points use terminals A15 (+), A14 (-) for set 1 and A13 (+), A12 (-) for set 2.

### Digital inputs

NPN isolated digital inputs (from switch, relay, open collector) or PNP 4mA use terminals A6 (IN1), A7 (IN2) and A4 (GND).

### Calibration output

For input from pressure probe, terminals B21, B22 are available for calibration contacts.

### Probe power output

Power for pressure probes, potentiometers, transmitters, available on terminals B20 (+Exc) and A3 (-Exc).

Available voltages are: 5V/200mA, 10V/200mA, 15V/200mA, 24V/100mA (see hardware configuration).

Any shielding on the probe connection cable must be connected to terminal A3 (-Exc).

### Repetition output W

Available at terminals A5 (+) and A4 (-) with output in voltage 0-10V or 0-20mA or 4-20mA isolated. Minimum and maximum can be corrected from panel keys (see calibration of repetition output).

### Power supply for potentiometer

10V (20mA max) voltage is available at terminal A16 (+VP) to power a potentiometer used to set a remote setpoint.

### MAIN control output

Available at terminals A22 (+) and A21 (-), standard 0-10V, 0-20mA, 4-20mA.

Minimum and maximum can be corrected from panel keys (see calibration of control output).

### Digital communication

- Type C.L. interface: reception diode available at terminals A10 (+Rx) and A11 (-Rx), transmission transistor at terminals A8 (+Tx) and A9 (-Tx).

Resistance in series to diode is 1K $\Omega$ , in series to transistor collector 100 $\Omega$ .

For connection in series, diode resistance is reduced to 100 $\Omega$  (see hardware configuration).

- Type RS485 4 wire interface (RS422 compatible): A11, A9 like A (data +) and A10, A8 like B (data -).

The transmission distance covered by the RS422/RS485 serial output reaches 500 meters with a maximum of 32 instruments connected.

For line lengths greater than 50 meters, and when a line termination impedance is required, solder jumpers X, Y, and Z on the Solder Side of board 45028.1 (see appendix).

Make the termination on the instrument farthest away on the serial connection chain.


### OUT1 alarm output

Relay output on terminals B16 (c), B15 (n.o.) and B14 (n.c.); contact capacity is 5A / 220V; isolated logic output (\*) type D2 24V/20mA max on terminals B16 (+) and B15 (-).

### OUT2 alarm output

Relay output on terminals B17 (n.c.), B18 (c) and B19 (n.o.); contact capacity is 5A/220V; isolated logic output (\*) type D2 24V/20mA max on terminals 19 (+) and 18 (-).

(\*) not isolation with respect to probe supply.



Equivalent scheme for D2 logic type output

### Instrument power supply

Power supply of 90/260Vac, 10/30Vdc/ac is applied to terminals B12 and B13.

## 6 • HARDWARE CONFIGURATION

To remove the electronic part of the case, turn the front screw until release, then remove manually. (Attention: high voltage due to residual loads on condensers). Configure by making jumpers on electronic boards of instrument.

### Configuration notes

Access to configuration and calibration depends on the position of jumpers on CPU board:

Jumper J3 ON (closed) = enable configuration.

Jumper S4 ON (closed) = enable calibration. (jumper S4 on solder side of CPU board)

## 6 • HARDWARE CONFIGURATION

See the Appendix to the manual for the drawings of the Power, CPU, and MAIN Output boards

### Power configuration for probe, transmitter or potentiometer

Based on the voltage level required, position the jumpers as follows:

POWER LEVEL	JUMPER			
	J5	J10	J15	J24
5V / 200mA	ON	OFF	OFF	OFF
10V / 200mA(*)	OFF	ON	OFF	OFF
15V / 200mA	OFF	OFF	ON	OFF
24V / 100mA	OFF	OFF	OFF	ON

Jumpers J5-J1-J15-J24 are on the components side of the power board

### Probe input configuration

For inputs 0-1V, 0-10V, 0-20mA, 4-20mA and potentiometer, position jumpers S3A, S3B, S3C and SI as follows:

INPUT TYPE	JUMPERS (♣)			
	S3A	S3B	S3C	SI
0 - 1V	ON	ON	OFF	OFF
0 - 10V e Transmitter 10V	OFF	OFF	OFF	OFF
Potenziometer	OFF	OFF	OFF	OFF
0-20mA / 4-20mA and Transmitter 20mA	ON	ON	OFF	ON
Strain gauge, 0-50mV, 0-60mV, 0-100mV (*)	OFF	OFF	ON	OFF

Configuration from panel keys is also necessary for all types of inputs (CGF.3, in.typ and In.cod parameters).

### Input configuration for remote setpoints

Based on the input required, position the jumpers as follows:

REMOTE SETPOINT INPUT TYPE	JUMPERS (♣)			
	S1A	S1B	S2A	S2B
Remote set 1 / 0-10V (*)	OFF	OFF		
Remote set 1/0-20mA/4-20mA	ON	ON		
Remote set 2 / 0-10V (*)			OFF	OFF
Remote set 2/0-20mA/4-20mA			ON	ON

### Digital input configuration

Based on the input required, position the jumpers as follows:

DIGITAL INPUT TYPE	JUMPERS (♣)			
	J1P	J1N	J2P	J2N
Input 1:NPN (*) voltage-free contact - open collector 24V/4mA	OFF	ON		
Input 1:PNP (24V/4mA)	ON	OFF		
Input 2:NPN (*) voltage-free contact - open collector 24V/4mA			OFF	ON
Input 2:PNP (24V/4mA)			ON	OFF

(♣) Jumpers are on CPU board, components side.

(\*) Standard configuration

### Configuration of repetition output W

Based on the output required, position the jumpers as follows:

REPETITION OUTPUT TYPE	JUMPERS (♣)		
	J5V	J5I	J6
0-10V o 2-10V	ON	OFF	ON
0-20mA o 4-20mA (*)	OFF	ON	OFF

### Configuration of MAIN control output

Based on the output required, position the jumpers as follows: (see main-out board)

MAIN OUTPUT TYPE	JUMPERS					
	J3	J4	J5	JS1	JS2	JS3
0-10V or 2-10V (*)	ON	ON	V	OFF	ON	OFF
±5V	ON	ON	V	ON	OFF	OFF
±10V	ON	OFF	V	OFF	OFF	ON
0-20mA or 4-20mA	OFF	ON	I	OFF	ON	OFF

During the power-on phase, the control output goes to minimum value (the MAIN ±5V output goes to -5V, ±10V to -10V).

### Configuration of C.L. (current loop) serial interface

Set the jumpers as per the table based on the type of connection you want:

TYPE OF CONNECTION	JUMPERS	
	S5	S6
Jumper (*)	OFF	ON
Series	ON	OFF

Jumpers S5, S6 are on CPU board, solder side.

(♣) Jumpers are on CPU board, components side.

(\*) Standard configuration

## 7 • SOFTWARE CONFIGURATION

Introduction to setting, configuration and calibration procedures:

The various steps are accessed by means of button F. Changes are made with the Raise and Lower keys.

### Main menu

**Normal operation** is characterized by:

- Process variable on display A
- Active setpoint on display B
- Control output in percentage on display C

The REM LED on indicates that the remote setpoint is active. The MAN LED flashing indicates setting of local control power value with the raise or lower key.

If no keys are pressed during data display on the main menu, timed return to normal functioning is activated. Press key F for a few seconds to access configuration steps. The following parameters are selected sequentially by means of key F (function).

### Displaying and setting local Setpoint

Access the setpoint display; you can import it if the protection level permits. Set the setpoint with the raise/lower keys within the maximum and minimum limits defined during configuration (CFG3/LO.SP/HI.SP). Press F to confirm the parameter value and go to the next step.

### Displaying remote inputs (SET1 REM, SET2 REM)

Remote inputs such as setpoint S.P.r.1 and/or S.P.r.2 are displayed in engineering value only if they are enabled as type 1...6 (CFG/tYP.1/tYP.2). Remote inputs such as percentage value Pot1 and/or Pot2 are displayed only if they are enabled as type 7...18 (CFG/tYP.1/tYP.2). Press F to go to the next step.

### Displaying ratio factor

The ratio factor is displayed only if the control has been defined as type 2 or 3, i.e., as ratio (CFG0/Ctr.t). It can be set in the range 0.00...99.99 if the protection level permits. The setting is subject to the same protection level as the setpoint. The value of r.t. = value of main input / value of enabled remote setpoint input (type 1 or 2 or 3) can be set or determined automatically at the time of manual- automatic *switching* if configuration parameter M.A.ty = 0. Press F to confirm the parameter value and go to the next step (see function notes).

### Displaying and setting trip points

Access the trip point display; it can be set if the protection level permits. During this step, the AL1 or AL2 LED will flash. Set with the raise/lower keys: if absolute, within the scale limits of the main input (CFG3/L.Lin/H.Lin); if reactive, within the range -1000...+1000. Press F to confirm the parameter value and return to normal operation.

## 8 • INFORMATION DISPLAY

### InFo

Access the display by keeping the F key pressed. The InFo message will appear on the display after a few seconds. Release the F key to enter the information display phase:

- Press the F key: the display will show the message **CodE** with the set serial communication code value;
- Press the F key: the display will show the message **UPdt** with the number of the software release used on the instrument;
- Press the F key: the display will show the message **Prot** with the set software protection level;
- Press the F key: you will return to the variable display.

## 9 • PARAMETERS SETTING

During normal operation, press the F key and release it when the display shows the message **dAtA**

### Parameters to be set if control is PID (Ctr.t = 0).

- \_Pb:** proportional band in range 0.1/800.0%.
- \_it:** integral time in range 00.0/99.9 sec. (by setting 0.0 the integral action is excluded). A weak integral action corresponds to a high integral time, while a strong integral action corresponds to a low integral time.
- \_dt:** derivative time in range 0.0/99.9 sec. (by setting 0.0 the derivative action is excluded). The effectiveness of the derivative action increases in proportion to the derivative time
- \_rSt:** manual reset in range -99/+99 scale points algebraically added to the setpoint value. After the control has settled, bring the value of the controlled variable exactly to the set setpoint (at times this is necessary in PD controls).
- PrSt:** reset power in range -100.0%/+100.0%. This contribution is added to the power calculated by the PID control.

- ArSt:** integral or antireset range, 0/9999 scale points (outside this range there is no updating of the integral power component); set 0 to exclude the action.
  - Atun:** type of autotuning:  
0 = action disabled; 1 = continuous;  
2 = One Shot enabled; 3 = One Shot activated.
- Per ulteriori informazioni vedere le note di funzionamento.
- \_FFd:** feed forward in range 0/100.0% or predictive action: coefficient of proportionality that multiplies the percentage value of the setpoint referred to the scale range (feedforward power = FFd \* SP%). This contribution is added to the power calculated by the control

### Parameter to be set if the control type (Ctr.t = 1) is self-adaptive.

- \_S.t :** delay time in range 0.1 - 100.0 sec.; corresponds to process speed; useful for compensating for system delay time.

## 9 • PARAMETERS SETTING

### Introduction

Configuration is performed in 5 steps:

- 0) **CFG0**: Control parameters, control output
- 1) **CFG1**: Machine code and Trip Point Hysteresis
- 2) **CFG2**: Protection level, I/O function, Serial
- 3) **CFG3**: Type of main inputs, remotes and retransmission output
- 4) **CFG4**: Linearization table

Access these steps by keeping the F key pressed until the message **\_CFG** appears and alternates with the value 0. Use the **Raise** and **Lower** keys to set the number of the configuration step that you want to access (value 0-4). Then press the **F** key to go directly to the step selected.

Press the **F** key to scroll the functions/parameters.

Access to the various configuration steps is subject to software protection (CFG.0/CFG.1) and hardware protection (CFG.2/CFG.3/CFG.4) according to the following table:

STEP	CONDITION FOR ENABLING
<b>CFG.0</b>	<b>Prot=</b> 0/1 (software protection level settable in CFG.2)
<b>CFG.1</b>	<b>Prot=</b> 0 (software protection level settable in CFG.2)
<b>CFG.2</b>	Jumper <b>J3</b> closed
<b>CFG.3</b>	Jumper <b>J3</b> closed
<b>CFG.4</b>	Jumper <b>J3</b> closed

*Jumper J3 on CPU board component side*

If there is protection, you will leave the configuration step and the display returns variable display.

### Configuration 0 (CFG.0)

**\_P.Lo**: Minimum power limit settable in range 0.0-100.0% ( $\pm 100.0\%$  if Out.C = 4 or 5) considered only in automatic.

**\_P.Hi**: Maximum power limit settable in range 0-100% ( $\pm 100\%$  if Out.C = 4 or 5) considered only in automatic.

**Out.G**: Maximum power gradient settable in range 0.1-99.9%/sec. Set 0 to exclude the limit. Not active in manual control

**S.P.Gr**: Setpoint gradient settable in range 0.1-99.9 digit/sec. with LrTy=1.  
By setting 0, switching between setpoints is immediate.

**Ctr.t**: Type of control:  
0 = PID control  
1 = PI self-adaptive control;  
2 = PID ratio control  
3 = PI self-adaptive ratio control.

**M.A.ty**: Type of switching mode from Manual to Automatic:  
0 = Setpoint value is set equal to that of variable and does not cause power variation in switching (for PID control, integral time it must be other than 0).  
1 = Setpoint remains unchanged: instrument starts control to reach setpoint (local or remote).

**A.M.ty**: Type of switching mode from Automatic to Manual:  
0 = absolute: power value is immediately brought to minimum value. Manual remote returns active if brought to values less than or equal to minimum  
1 = deviation: power value does not change, maintains value it had in automatic. Can be increased or decreased with Raise/Lower keys (if in local manual) or by changing input enabled for manual remote (if in local manual).  
2 = absolute, setpoint remains unchanged. Control

output assumes percentage value of remote input enabled as manual remote. If manual remote selection is not active, behavior is similar to type 1.  
3 = deviation, power does not change, maintains the value it had in automatic, forcing digital remote power to the same value. The digital remote power value can be freely raised or lowered with the remote Raise and Lower keys (motopotentiometer simulation function). Mode 3 is enabled only for digital remote manual (motopotentiometer; tYP1 = 39 p tyP.2 = 39) and with positive control output: 0/2 - 10V, or 0/4-20mA.

**L.r.ty**: Type of switching mode between local setpoint and remote setpoint:

0 = immediate switching from Local to Remote;  
1 = switching with set gradient S.P.Gr; from SPLOC to SPPr  
2 = on the remote to local switch, the local setpoint value assumes the remote setpoint value;  
3 = on the local to remote switch, the setpoint variation gradient S.P.Gr; on the remote to local switch, the local setpoint value assumes the remote setpoint value;  
+4 = to inhibit writing on EEPROM of local setpoint transmitted via serial.

**P.On.t**: Type of Power on, conditions set at power-on:

0 = automatic function with local setpoint  
1 = manual function with local control; control output at minimum value;  
2 = automatic function with remote setpoint, provided that TYOP or 2 is configured;  
3 = manual function with remote control; control output at minimum value, provided that TYP1 or TYP2 is configured;  
(if A.M.ty = 2 control output assumes value of remote input).  
4 = function at last-saved state (state set by digital input IN1 or IN2 takes priority).

**Out.C**: type of MAIN output control

Out.C	OUTPUT TYPE
<b>0 (*)</b>	0-10V or 0-20mA direct
<b>1</b>	0-10V or 0-20mA indirect
<b>2</b>	2-10V or 4-20mA direct
<b>3</b>	2-10V or 4-20mA indirect
<b>4</b>	$\pm 10$ ( $\pm 5$ ) direct**
<b>5</b>	$\pm 10$ ( $\pm 5$ ) indirect**

\* Standard configuration

\*\* See power limit settings P.Lo - P.Hi

## 9 • PARAMETERS SETTING

### Configuration 1 (CFG.1)

**CodE** Instrument code in range 0/9999  
**HYS1** Hysteresis for OUT1 in range -1000/+1000.  
**HYS2** Hysteresis for OUT2 in range -1000/+1000.

A negative (or positive) number indicates a hysteresis range positioned under (or over) the selected limit, and is typical of a direct (or inverse) trip point. If the output function considers the trip delay instead of hysteresis, the setting is in the range 0/9999 msec. (resolution 2msec. for OUT1 and OUT2).

### Configuration 2 (CFG.2)

Use the F key to confirm set values and go to setting of the next parameter.

**Prot** Software protection level according to table:

"Prot"	DISPLAY	CHANGE
0	- read input - setpoint - trip points - Step "INFO" - Step "dAtA" - Step "CFG.0/1"	- setpoint - trip points - Step "CFG.0/1" - Step "dAtA"
1	- read input - setpoint - trip points - Step "INFO" - Step "dAtA" - Step "CFG.0"	- setpoint - trip points - Step "dAtA" - Step "CFG.0"
2	- read input - setpoint - trip points - Step "INFO" - Step "dAtA"	- setpoint - trip points - Step "dAtA"
3	- read input - setpoint - trip points - Step "INFO"	- setpoint - trip points
4	- read input - setpoint - trip points	- setpoint
5	- read input - setpoint	
8	To disable access to calibration	

(\*) Standard protection level is 2.

Remember that Jumper J3 = ON enables access to CFG2, CFG3, CFG4.

**bAud:** Serial communication transmission speed, according to table

**Sr.P** Serial interface protocol  
 0 CENCAL GEFTRAN  
 1 MODBUS

**bAu** Baudrate

bAu	Baudrate	Interface
0	1200	CL / 485 / 232
1	2400	485 / 232
2	4800	485 / 232
3	9600	485 / 232
4	19200	485 / 232

PAR	Parity
0	No parity
1	Odd
2	Even

**but.1** **PEAK** key function  
**0** no function (key not active)  
**1** activate "peak +" (maximum) (\*)  
**2** activate "peak -" (minimum)  
**3** activate "peak-peak" (max. peak - min. peak)

**but.2** **CAL/RST** key function  
**0** no function (key not active)  
**1** reset trip memory  
**2** reset peak memory  
**3** reset trip memory + reset peak memory (\*)  
**4** enable/disable remote set (•)  
**5** select Manual local/Automatic  
**6** select Manual remote/Automatic (••)  
**7** calibration control (only for strain gauge 6-wire type probes)

**but.3** **MAN/AUTO** key function  
**0** no function (key not active)  
**1** reset trip memory  
**2** reset peak memory  
**3** reset trip memory + reset peak memory  
**4** enable/disable remote set (•)  
**5** select Manual local/Automatic (\*)  
**6** select Manual remote/Automatic (••)  
**7** calibration control (only for strain gauge 6-wire type probes)

**d.i.F.1** digital input 1 function  
**0** no function (key not active) (\*)  
**1** reset trip memory  
**2** reset peak memory  
**3** reset trip memory + reset peak memory  
**4** enable remote set (•)  
**5** select Manual local  
**6** select Manual remote (••)  
**7** calibration control (only for strain gauge 6-wire type probes)  
**8** **HOLD** sampled input value function: (sampled input value, trip points, control are "frozen" for the time the input is active).  
**9** control probe supply. Digital input 1 (IN1) used to determine probe supply control must be type PNP polarized (see configuration of digital inputs). The digital input has to be connected in parallel to the probe supply. Connect terminals 4 to -Exc, terminals 6 (diF1) to +Exc. If power fails to the probe, the display shows e.br; the outputs go to configuration state (rEL).  
**10** Power-off function (see function notes)

**d.i.F.2** digital input 2 function  
**0** no function (key not active) (\*)  
**1** reset trip memory  
**2** reset peak memory  
**3** reset trip memory + reset peak memory  
**4** enable remote set (•)  
**5** select Manual local  
**6** select Manual remote (••)  
**7** calibration control (only for strain gauge 6-wire type probes)  
**8** **HOLD** sampled input value function: (sampled input value, trip points, control are "frozen" for the time the input is active).

## 9 • PARAMETERS SETTING

**9** control probe supply. Digital input 2 (IN2) used to determine probe supply control must be type PNP polarized (see configuration of digital inputs). The digital input has to be connected in parallel to the probe supply. Connect terminals 4 to -Exc, terminals 6 (diF1) to +Exc. If power fails to the probe, the display shows e.br; the outputs go to configuration state (rEL).

**10** Power-off function (see function notes)

- (•) *Rem. set enabled: REM LED on if tYPr1 and/or tYPr2 also enabled in CFG3.*
- (••) *Value of main output is controlled by remote if remote inputs are configured (TyP.1 and TyP.2) for remote manual*  
**N.B.** IN1 and IN2 are set as diF1 = 5 and diF2 = 6, the second has priority.

**out.1** output 1 function  
(see trip point function)

**0** direct absolute

(**direct** function same as having an energized relay for values above set trip point). (\*)

**1** inverse absolute

(**inverse** function same as having an energized relay for values below set trip point).

**2** direct deviation referred to setpoint

**3** inverse deviation referred to setpoint

**4** direct **symmetrical** deviation (window) referred to setpoint. Relay energized outside

**5** inverse **symmetrical** deviation (window) referred to setpoint.

**+8** inverse **symmetrical** deviation (window) referred to setpoint until the first alarm (functions only in case of inverse alarm).

**+16** to code selected for trip point with memory.

**+32** to code selected for probe interrupt or power failure alarm (in this case, use DIGITAL INPUT 1 configured d.i.F.1= 9). Relay state depends on parameter rEL.

The output functions normally when the probe is not interrupted.

**+64** to code selected timed trip point delay (in this case, hysteresis is set in msec. and becomes the delay time in activation of output compared to time of tripping).

**+128** assigned to setpoint value only for absolute trip point.

**out.2** output 2 function  
See **out.1**

**\_rEL** behavior of trip relays in case of broken probe (energizing and/or signal); setting according to following table:

Code rEL	Behavior of relay in case of:		
	BREAK+	BREAK-	EXCIT±
<b>0(*)</b>	OFF	OFF	OFF
<b>1</b>	OFF	OFF	ON
<b>2</b>	OFF	ON	OFF
<b>3</b>	OFF	ON	ON
<b>4</b>	ON	OFF	OFF
<b>5</b>	ON	OFF	ON
<b>6</b>	ON	ON	OFF
<b>7</b>	ON	ON	ON

### Configuration 3 (CFG.3).

Use the **F** key to confirm set values and go to setting of next parameter.

**I.t.YP** type of input e polarization:

Code rEL	Behavior of relay in case of:	
<b>0(*)</b>	Strain gauge (Pressure, force, etc.)	POSITIVE (ex. 0...10mV)
<b>1</b>		SYMMETRICAL (ex. -5...5mV)
<b>2</b>		NEGATIVE (ex. 0...10mV)
<b>4</b>	Linear (V, I, Pot.)	POSITIVE (ex. 0...10mV)
<b>5</b>		SYMMETRICAL (ex. -5...5mV)
<b>6</b>		NEGATIVE (ex. 0...10mV)
<b>+8</b>	Custom Linearization (*)	
<b>+16</b>	To select the input filter in tenths of a second (see <b>Filt</b> parameter)	

(•) *In this case, set the custom linearization table to 32 segments (see CFG.4).*

(••) *For symmetrical linear inputs, the signal range is divided; for example, if I.t.YO = 5 and I.Cod = 2, the signal may be +/- 50mV.*

(\*) *Standard configuration*

*CUSTOM linearization does not permit symmetrical polarization.*

## 9 • PARAMETERS SETTING

**I.Cod** sensitivity identification code at input

STRAIN GAUGE		LINEAR	
In.Cod	Sensitivity	In.Cod	Sensitivity
0	1,5mV/V Ecc = 5V	0	0-50mV
1	2	1	0-60mV
2	2.5	2	0-100mV
3	3	3	0-1V
4	3.3	4	0-10V
5	1,5mV/V Ecc = 10V	5	0-20mA
6	2	6	4-20mA
7(*)	2.5	7	Potentiometer: >350Ω Power: 10V
8	3		
9	3.3		
10	1,5mV/V Ecc = 15V		
11	2		
12	2.5		
13	3		
14	3.3		
15(*)	Trasmitter 0-10V		
16(*)	Trasmitter 0-20mA		
17(*)	Trasmitter 4-20mA		

(\*) Codes 15, 16, 17 permit only positive polarization

In.tYP = 0

Codes 6 and 7 (linear) permit only positive polarization:  
In.tYP = 4

**Note:**

for input 4...20mA, current below 2mA generates message L.Sbr and associated relay state specified with parameter \_rEL.

**Filt** constant programming of digital filter time, settable in range 0.0...20.0 sec. (resolution 0.01 sec.) or 0.0...20.0 sec (resolution 0.01 sec.) see **I.tYP** parameter. It is advisable to turn on the filter at the limit of the admitted trip time.  
Set = 0 to turn off filter.

**Fild** constant programming of digital filter time on display. Value settable in range 0...9.9 sec. Set -0 to turn off filter. Does not affect trip time.

**dEC.P** position of decimal point or number of decimal digits in range 0/1/2/3.

**oFSt** offset of input in range -1000/+1000 in scale units.

**L.Lin** Minimum linear scale value for input in range -1999/+9999.  
For symmetrical signals, corresponds to zero value; i.e., if you want an indication of ±1000, L.Lin equals 0.

**H.Lin** Maximum linear scale value for input in range -1999/+9999 (value must be > Lo.Lin).

**tYP.1** type of signal and assigned function for remote input 1 (see configuration table):

**tYP.2** type of signal and assigned function for remote input 2 (see configuration table):

tYP.1/2	CONFIGURATION OF REMOTE INPUTS
0(*)	Remote input not enabled
1(**)	Remote absolute set 0-10V
2	Remote absolute set 0-20mA
3	Remote absolute set 4-20mA
4	Remote relative set 0-10V
5	Remote relative set 0-20mA
6	Remote relative set 4-20mA
7	Manual remote 0-10V
8	Manual remote 0-20mA
9	Manual remote 4-20mA
10***	Reference for control output 0-10V
11***	Reference for control output 0-20mA
12***	Reference for control output 4-20mA
13	Limitation of minimum for control output 0-10V
14	Limitation of minimum for control output 0-20mA
15	Limitation of minimum for control output 4-20mA
16	Limitation of maximum for control output 0-10V
17	Limitation of maximum for control output 0-20mA
18	Limitation of maximum for control output 4-20mA
+ 32	for motopotentiometer function (requires remote input, which powers the remote buttons, configured to 0-10V)

\*Standard configuration for tYP.2  
\*\*Standard configuration for tYP.1  
\*\*\* Reference for control output: adds control power to remote input value.

In case of selection tYP1 = tYP2, tYP1 is considered active for the same type of function.

**Lo.SP** lower limit for setpoints (locals or remotes in scale range -1999/+9999)  
(may be higher than Hi.SP).

**Hi.SP** upper limit for setpoints (locals or remotes in scale range 1999/+9999)  
(may be lower than Lo.SP).

In case of deviation remote setpoint, setting range for local set is the same as the scale limits of the variable (L.Lin e H.Lin).

**out.t** type of signal in output **W** (retransmission of input signal) according to table:

	RETRANSMITTED VARIABLE	SIGNAL TYPE
0(*)	Input (displayed value)	0-10V or 0-20mA
1	Peak + (maximum)	
2	Peak - (minimum)	
3	Peak - peak	
4	Trip point 1	
5	Trip point 2	
6	Direct main output	
7	Inverse main output	
8	Deviation (setpoint - input)	
9	Deviation (input - setpoint)	
10	Setpoint	
11	Remote input 1	
12	Remote input 2	

**Note:** Add +16 to code 0-12 to obtain output type 2-10V or 4-20mA

## 9 • PARAMETERS SETTING

**Lo.tr** start scale limit for retransmission output in range  
- 1999/9999.

**Hi.tr** full scale limit for retransmission output in range  
- 1999/9999.  
(Lo.tr may be higher than Hi.tr).

Limits Lo.tr and Hi.tr are not considered in case of out.t = 6,7 in which a 0-100% scale is forced 0-100% ( $\pm 100\%$  if Out.t = 11,12 if tYP.1 or tYP.2 > 6.

### Configuration 4 (CFG.4).


Setting custom linearization table in 32 segments.

**ATTENTION:** before setting, you must know the various corresponding values between the input signal and the engineering units scale (see example of linearization).

Press **F** to scroll the 33 values of the linearization table in scale units:

**St.0** Set starting point (scale start)  
**St.1** Set point 1  
**St.2** Set point 2  
.....  
**St.32** Set point 32 (full scale)

### EXAMPLE OF LINEARIZATION



Positive polarization signals (eX. 0-50mV) St.0 is value displayed for minimum input (eX. 0mV); St.32 is value displayed for maximum input (es.50mV).

## 10 • CALIBRATIONS

### IMPORTANT:

the instruments are supplied pre-calibrated, run the procedure only if absolutely necessary.

Start calibration with the instrument on for at least 5-10 minutes. To access the calibration menu, keep the **F** key pressed until the message **\_CAL** appears on the display in alternation with value 0.

Access is subject to jumper **S4 = ON** and to software protection Prot in CFG2. Automatic calibration of the strain gauge probes (CAL.8) can be accessed directly simply by pressing the "**F**" and "**Raise**" keys simultaneously for about 4 seconds. Access is not subject to hardware protection, but only to software protection; set (CFG/2) PROT + 8 in configuration to disable direct access to step CAL.8. Once step CAL.8 is reached, run the following procedures as described in the manual.

The calibration menu can be accessed directly by pressing the **F**, **Inc**, **Dec** keys simultaneously; this access is subject only to software protection by means of the Prot parameter in configuration CFG.2.

The calibration menu has 13 items:

- 1 Calibration 50mV, 60mV or 100mV (CAL.1)
- 2 Calibration 1V (CAL.2)
- 3 Calibration 10V (CAL.3)
- 4 Calibration 20mA (CAL.4)
- 5 Manual calibration of pressure probe (CAL.S)
- 6 Automatic calibration of pressure probe (CAL.A)
- 7 80% automatic calibration of pressure probe (CAL.8)
- 8 Calibration of potentiometer input (CAL.P)
- 9 Calibration of remote input 1 (CA.S1)
- 10 Calibration of remote input 2 (CA.S2)
- 11 Calibration of repetition output (CA.rt)
- 12 Calibration of MAIN output
- 13 Reset factory calibration

Use the "**Raise**" and "**Lower**" keys to set the key code for the calibration step to be accessed (value 1 - 13). Then press the **F** key to go directly to the step **ONLY** if the set code

corresponds to a probe type conforming to instrument configuration (**tYP**); the display will show the message corresponding to the type of calibration selected. If protection is active, you will exit the calibration menu and return to display of the variable.

By pressing the **F** key with key code = 0 you quit the calibration procedure and return to display of the variable.

### -CAL.1 (for 0-50mV / 0-60mV / 0-100V linears)

Calibration (key code 1) for 50mV/60mV/100mV inputs. The display shows the message:

- CAL.1** Make electrical connections as instructed in specific section. Press the **F** key to continue.
- C.\_0\_** Put a 0V signal between inputs of terminals 1 (+) and terminals 2 (-). Press the **F** key to continue
- C.50\_** Put a 50mV, 60mV or 100mV signal (25mV, 30mV, 50mV for symmetrical signal) between inputs of terminals 1 (+) and terminals 2 (-). Press the **F** key to end the procedure. The message **\_CAL** with value **0** will appear on the display. Press the **F** key to exit the calibration menu or set the code for a new calibration.

### -CAL.2 (for 0-1V linears)

Calibration (key code 2) for 1V input.  
The display shows the message:

- CAL.2** Make electrical connections as instructed in specific section. Press the **F** key to continue.
- C.\_0\_** Put a 0V signal between inputs of terminals 1 (+) and terminals 2 (-). Press the **F** key to continue
- C.\_1\_** Put a 1V signal (0.5V for symmetrical signal) between inputs of terminals 1 (+) and terminals 2 (-). Press the **F** key to end the procedure. The message **\_CAL** with value **0** will appear on the display. Press the **F** key to exit the calibration menu or set the code for a new calibration.

## 10 • CALIBRATIONS

### -CAL.3 (for 0-10V linears)

Calibration (key code 3) for 0-10V input.

The display shows the message:

- CAL.3** Make electrical connections as instructed in specific section. Press the **F** key to continue.
- C.\_0\_** Put a 0V signal between inputs of terminals 1 (+) and terminals 2 (-). Press the **F** key to continue
- C.10\_** Put a 10V signal (5V for symmetrical signal) between inputs of terminals 1 (+) and terminals 2 (-).  
For inputs from transmitter: CAL output is activated during calibration to obtain the calibration value.  
Press the **F** key to end the procedure.  
The message **\_CAL** with value **0** will appear on the display. Press the **F** key to exit the calibration menu or set the code for a new calibration.

### -CAL.4 (for 0-20mA / 4-20mA linears)

Calibration (key code 4) for 0-20mA / 4-20mA input.

The display shows the message:

- CAL.4** Make electrical connections as instructed in specific section. Press the **F** key to continue.
- C.\_0\_** Put a 0mA signal between inputs of terminals 1 (+) and terminals 2 (-). Press the **F** key to continue
- C.\_20** Put a 20mA signal (10mA for symmetrical signal) between inputs of terminals 1 (+) and terminals 2 (-).  
For inputs from transmitter: CAL output is activated during calibration to obtain the calibration value.  
Press the **F** key to end the procedure.  
The message **\_CAL** with value **0** will appear on the display. Press the **F** key to exit the calibration menu or set the code for a new calibration.

### -CAL.S (for 6-4 wire strain gauge pressure probe and transmitters)

Calibration (key code 5) for pressure input for 4 or 6-wire strain gauge probe with manual sequence.

The display shows the message:

**CAL.G** Make electrical connections as instructed in specific section. Use the "Raise/Lower" keys to set the calibration value indicated on each probe, approximately 80% of full scale. Press the **F** key to continue.

**PrS.1** Put a signal corresponding to minimum pressure (equivalent to probe drained) between inputs of terminals 1 (+) and terminals 2 (-). Press the **F** key to continue.

**PrS.2** In case of 6-wire probe, the instrument will automatically unbalance the pressure probe and acquire the calibration value.

**Attention:** the probe must be drained. In case of 4-wire probe, put a signal corresponding to the set calibration value at instrument input, or load the probe in an equivalent manner. Press the **F** key to end the procedure. The message **\_CAL** with value **0** will appear on the display. Press the **F** key to exit the calibration menu or set the code for a new calibration.

### -CAL.A (for 6- wire strain gauge pressure probe)

Calibration (key code 6) for pressure input for 6-wire strain gauge probe with manual sequence.

**Attention:** the probe must be drained. The display shows the message:

**CAL.A** Make electrical connections as instructed in specific section and check that the probe is drained. Use the "Raise/Lower" keys to set the calibration value indicated on each probe, approximately 80% of full scale. Press the **F** key to continue.

**PrS.1** Wait for stabilization and acquisition of minimum value; automatically goes to next step

**PrS.2** Unbalancing of probe, wait for stabilization and acquisition of calibration value equal to value shown on probe (approximately 80% of full scale value); automatically goes to end of procedure and returns to normal functioning.

### -CAL.8 (for 6- wire strain gauge pressure probe, 80% cal.)

Calibration (key code 7) for pressure input for 6-wire strain gauge probe, calibrated to exactly 80% of full scale with automatic sequence.

**Attention:** the probe must be drained.

The display shows the message:

**PrS.1** Wait for stabilization and acquisition of minimum value; automatically goes to next step.

**PrS.2** Unbalancing of probe, wait for stabilization and acquisition of calibration value equal to value shown on probe (approximately 80% of full scale value); automatically goes to end of procedure and returns to normal functioning.

### -CAL.P (for potentiometer input)

Calibration of potentiometer input (key code 8).

The display shows the message:

**CAL.P** Make electrical connections as instructed in specific section. Press the **F** key to continue.

**L.Pot** Position the potentiometer cursor at start of stroke. Press the **F** key to continue.

**H.Pot** Position the potentiometer cursor at end of stroke. Press the **F** key to end the procedure. The message **\_CAL** with value **0** will appear on the display. Press the **F** key to exit the calibration menu or set the code for a new calibration.

### -CA.S1 (for remote input 1)

Calibration of remote input 1 (key code 9): for 0-10mV/0-20mA inputs. The display shows the message:

**CA.S1** Make electrical connections as instructed in specific section. Press the **F** key to continue.

**LO.S1** Supply minimum value to remote input 1 (if input from potentiometer, position the potentiometer cursor at start of stroke). Press the **F** key to continue.

**HI.S1** Supply maximum value to remote input 1 (if input from potentiometer, position the potentiometer cursor at end of stroke). Press the **F** key to end the procedure. The message **\_CAL** with value **0** will appear on the display. Press the **F** key to exit the calibration menu or set the code for a new calibration.

### -CA.S2 (for remote input 2)

Calibration of remote input 2 (key code 10): for 0-10V/0-20mA inputs (see hardware configuration). For 4-20mA input, calibrate as if it were 0-20mA. The display shows the message:

**CA.S2** Make electrical connections as instructed in specific section. Press the **F** key to continue.

**LO.S1** Supply minimum value to remote input 2 (if input from potentiometer, position the potentiometer cursor at start of stroke). Press the **F** key to continue.

**HI.S1** Supply maximum value to remote input 2 (if input from potentiometer, position the potentiometer cursor at end of stroke). Press the **F** key to end the procedure. The message **\_CAL** with value **0** will appear on the display. Press the **F** key to exit the calibration menu or set the code for a new calibration.

## 10 • CALIBRATIONS

### -CA.rt (for retransmission output)

Calibration of repetition output (key code 11):  
for 0-10mV/0-20 mA inputs (see hardware configuration).  
For 4-20mA input, calibrate as if it were 0-20mA.  
The display shows the message:

- CA.rt** Make electrical connections as instructed in specific section. Press the **F** key to continue.
- L.out** With the "Raise/Lower" keys, correct the offset of the minimum output signal in range -300/+1999. Press the **F** key to continue.
- H.out** With the "Raise/Lower" keys, correct the maximum output signal in range -300/+1999. Press the **F** key to end the procedure. The message **\_CAL** with value **0** will appear on the display. Press the **F** key to exit the calibration menu or set the code for a new calibration.

### -CA.Po (for MAIN output)

Calibration of repetition output (key code 12):  
Calibration refers to type of signal selected: 0-10V, 0-20mA, ±10V, ±5V. The display shows the message: **CA.Po**.  
Make electrical connections as instructed in specific section.  
Press the **F** key to continue.

- L.out** With the "Raise/Lower" keys, correct the offset of the minimum output signal in range -300/+1999. 0V for signals ±10V, ±5V. Press the **F** key to continue.
- H.out** With the "Raise/Lower" keys, correct the maximum output signal in range -1999/+300. Press the **F** key to end the procedure. The message **\_CAL** with value **0** will appear on the display. Press the **F** key to exit the calibration menu or set the code for a new calibration.

## 11 • FUNCTION NOTES

### Absolute trip point

Setpoint set with absolute value with respect to 0.  
(eX. Out1=450, Out2=350). The setting range assumes maximum values of selected scale.

### Deviation trip point

Setpoint set with reference to setpoint value  
eX. Out1 absolute, Out deviation:  
Out1=400, Setpoint=500, Out2=50 (trip point at 550)  
The setting range assumes values -999/+999; set value is algebraically added to setpoint value.

### Direct trip point

Relay energized with variable above value of set trip point for both absolute and deviation type.

### Inverse trip point

Relay energized with variable below value of set trip point for both absolute and deviation type.

### Symmetrical deviation trip point

Value set relative to setpoint is both added and subtracted to create a trip window.  
This is defined direct (inverse) symmetrical deviation with relay energized for values outside (inside) the window

### Calibration control function

Activated by key or by specifically configured digital input. It involves:

- blocking of trip points
- closing of calibration contact (terminals 21B and 22B)
- lighting of CAL LED
- display of input corresponding to value supplied by probe or transmitter for activation time of key or of digital input.

### Feed-Forward function

The Feed-Forward or predictive action function is particularly effective in controlling linear processes characterized by significant variations of setpoint.

It supplies a contribution to the output that is proportional to the difference between the setpoint value to be reached and the start of scale value according to the formula

$$OUT\% = \frac{KF \cdot (SET - i.s.)}{(f.s. - i.s.)}$$

where:

**OUT%** = contribution of Feed-Forward function to output.

**KF** = coefficient of Feed-Forward.

**SET** = setpoint value

**f.s.** = full scale value

**i.s.** = start scale value

**f.s.-i.s.** = scale amplitude

What is actually set on the instrument is coefficient KF, which can be expressed according to the formula

$$OUT\% = \frac{OUT\% \cdot (f.s. - i.s.)}{(SET - i.s.)}$$


by which KF is known by knowing a priori the OUT% value so that the process can be controlled on the SET required (hence the name predictive action). For example, a process with setpoint at 400 bar requires an output equal to OUT%=35, and the instrument scale is 0-1000 bar

$$OUT\% = \frac{35\% \cdot 1000}{400} = 87,5\%$$

The predictive action leads the instrument to control in the "vicinity" of the rated condition, and therefore allows (if appropriately calculated) reduced contribution of the integral action and better dynamic behavior of the process under control.

### Manual Tuning Technique

- A) Set the working setpoint value.
- B) Set the proportional band to 0.1%. Cancel the integral and derivative actions
- C) Switch to automatic and observe the trend of the variable: you will see behavior similar to that in the figure:



## 11 • FUNCTION NOTES

D) Calculation of PID parameters: proportional band value

$$P.B. = \frac{\text{Peak} \cdot 100}{V.\text{max.} - V.\text{min.}}$$

Vmaximum - Vminimum is scale range.

Integral time value  $I_t = 1,5 \cdot T$

Derivative time value  $d_t = I_t / 4$

E) Switch the controller to manual, set the calculated parameters (re-enable the PID control by setting a cycle time for relay outputs), switch to automatic

F) If possible, to assess optimization of parameters, change the setpoint value and check transient behavior: if oscillation persists, increase the proportional band value; if response is too slow, decrease the value.

### Notes on behavior of Autotuning

Enabling the autotuning function blocks PID parameter settings. It can be either permanent or single.

The first type continues to evaluate the oscillations of a system by trying to evaluate as soon as possible the PID parameter values that reduce oscillation. It does not engage if oscillations drop to values below 0.5% of the proportional band. It is interrupted in case of variation, and resumed automatically with constant setpoint. The calculated parameters are not saved - if the instrument is turned off, the controller restarts with the parameters programmed before autotuning was engaged.

Single-action autotuning is useful for calculating output power around the setpoint. It produces a variation on the control output of 10% of current value, and evaluates the effects in overshoot over time. These parameters are saved and replace the ones set previously. After this disturbance, the controller resumes control of the setpoint with the new parameters.

### Ratio controller

During normal function, the instrument correctly displays:

- the value of the process variable on display A
- the setpoint value (=remote set input for ratio r.t.) on display B
- power value on display C

If M.A.ty (manual to automatic switching mode) = 0, ratio r.t. between main input and remote input is calculated a MAN ---->AUTO switching. The functionality of this control lets you maintain the main variable at a defined ratio with an external reference. The application type is relative to a master-slave speed control.

Example of configuration:

PID ratio control (Ctr.t=2)

Main input with scale 0,...,1000 (dEC.P = 0, H.Lin = 1000).

Remote input 2 as absolute remote set with scale 0,...,1000

(tYP.2 = 1 or 2 or 3, Lo.SP=0, Hi.SP=1000).

### "Power off" function

Typical application: protects extruders in case of alarm conditions. This function is obtained by setting diF =10 or dif2 = 10.

The digital input ON (active) forces the control output to zero both in automatic and in manual.

Digital local manual or remote manual power is forced to zero. To resume control, the instrument must be switched to manual (if in automatic). At this point, by putting the digital input OFF, the "Power off" state ends and the instrument resumes manual power control.

### Motopotentiometer function

By setting tYP1 + 32 or tYP2 + 32 you enable the control (from the remote buttons) of the value corresponding to the function selected in tYP1 or tYP2.

Electrical connections

SPR1

Connect: raise button to terminals 14-15, lower button to terminals 14-19. Also link terminal 16 to 17 and terminal 15 to 18 SPR2 (alternate to SPR1)

Connect: raise button to terminals 12-13, lower button to terminals 12-19. Also link terminal 16 to 17 and terminal 13 to 18


Example:

tYP1 = 39 (7+32) means that remote manual power is set by means of remote buttons RAISE and LOWER.

### Note:

This function requires a remote input (which powers the remote buttons) configured to 0-10V (see software configuration parameters tYP1, respectively tYP2 in CFG3 and CPU board hardware configuration).

## 13 • ORDER CODE



## • WARNINGS



**WARNING:** this symbol indicates danger. It is placed near the power supply circuit and near high-voltage relay contacts

**Read the following warnings before installing, connecting or using the device:**

- follow instructions precisely when connecting the device.
- always use cables that are suitable for the voltage and current levels indicated in the technical specifications.
- the device has NO On/Off switch: it switches on immediately when power is turned on. For safety reasons, devices permanently connected to the power supply require a two-phase disconnecting switch with proper marking. Such switch must be located near the device and must be easily reachable by the user. A single switch can control several units.
- if the device is connected to electrically NON-isolated equipment (e.g. thermocouples), a grounding wire must be applied to assure that this connection is not made directly through the machine structure.
- if the device is used in applications where there is risk of injury to persons and/or damage to machines or materials, it MUST be used with auxiliary alarm units. You should be able to check the correct operation of such units during normal operation of the device.
- before using the device, the user must check that all device parameters are correctly set in order to avoid injury to persons and/or damage to property.
- the device must NOT be used in inflammable or explosive environments. It may be connected to units operating in such environments only by means of suitable interfaces in conformity to local safety regulations.
- the device contains components that are sensitive to static electrical discharges. Therefore, take appropriate precautions when handling electronic circuit boards in order to prevent permanent damage to these components

**Installation:** installation category II, pollution level 2, double isolation

- power supply lines must be separated from device input and output lines; always check that the supply voltage matches the voltage indicated on the device label.
- install the instrumentation separately from the relays and power switching devices
- do not install high-power remote switches, contactors, relays, thyristor power units (particularly if "phase angle" type), motors, etc... in the same cabinet.
- avoid dust, humidity, corrosive gases and heat sources
- do not close the ventilation holes; working temperature must be in the range of 0...50°C

If the device has faston terminals, they must be protected and isolated; if the device has screw terminals, wires should be attached at least in pairs.


• **power:** supplied from a disconnecting switch with fuse for the device section; path of wires from switch to devices should be as straight as possible; the same supply should not be used to power relays, contactors, solenoid valves, etc.; if the voltage waveform is strongly distorted by thyristor switching units or by electric motors, it is recommended that an isolation transformer be used only for the devices, connecting the screen to ground; it is important for the electrical system to have a good ground connection; voltage between neutral and ground must not exceed 1V and resistance must be less than 60hm; if the supply voltage is highly variable, use a voltage stabilizer for the device; use line filters in the vicinity of high frequency generators or arc welders; power supply lines must be separated from device input and output lines; always check that the supply voltage matches the voltage indicated on the device label

• **input and output connections:** external connected circuits must have double insulation; to connect analog inputs (TC, RTD) you have to: physically separate input wiring from power supply wiring, from output wiring, and from power connections; use twisted and screened cables, with screen connected to ground at only one point; to connect adjustment and alarm outputs (contactors, solenoid valves, motors, fans, etc.), install RC groups (resistor and capacitor in series) in parallel with inductive loads that work in AC (*Note: all capacitors must conform to VDE standards (class x2) and support at least 220 VAC. Resistors must be at least 2W*); fit a 1N4007 diode in parallel with the coil of inductive loads that operate in DC

**GEFRAN spa will not be held liable for any injury to persons and/or damage to property deriving from tampering, from any incorrect or erroneous use, or from any use not conforming to the device specifications.**

**CONNESSIONI  
CONNECTIONS  
ANSCHLÜSSE**

**CONNEXIONS  
CONEXIONES  
CONEXÕES**



**Ingresso 0- 20mA o 4-20mA  
0- 20mA or 4-20mA input**


Configurazione  
Configuration  
Konfiguration  
Configuration  
Configuración  
Configuração

**Eingang 0- 20mA / 4-20mA  
- Entrée 0- 20mA ou 4-20mA**

Ingresso sonda:  
Probe input:  
Sensoreingang:  
Entrée capteur:  
Entrada sonda:  
Entrada da sonda:

**Entrada 0- 20mA / 4-20mA  
Entrada 0- 20mA / 4-20mA**

S3A (ON)  
S3B (ON)  
S3C (OFF)  
SI (ON)




**Ingresso da trasmettitore 4-20mA**  
4-20mA Input from transmitter

**Transmittereingang 4-20mA**  
Entrée par transmetteur 4-20mA

**Entrada desde transmisor 4-20mA**  
Entrada do transmissor 4-20mA

Configurazione Ingresso sonda:	Configuration Probe input:	Konfiguration Sensoreingang:	Configuration Entrée capteur:	Configuración Entrada sonda:	Configuração Entrada sonda:
S3A (ON)	S3B (ON)	S3C (OFF)	SI (ON)		
Alimentazione Trasmettitore Transmitter power		Transmitterspeisung Alimentation transmetteur		Alimentación transmisor Alimentação do transmissor	
24V (J24 = ON, J5 = J10 = J15 = OFF)					




**Ingresso Potenzimetro**  
Potentiometer input

**Potentiometereingang**  
Entrée potentiomètre

**Entrada potenciómetro**  
Entrada do potenciómetro

Configurazione Ingresso sonda:	Configuration Probe input:	Konfiguration Sensoreingang:	Configuration Entrée capteur:	Configuración Entrada sonda:	Configuração Entrada sonda:
S3A (OFF)	S3B (OFF)	S3C (OFF)	SI (OFF)		
Alimentazione Potenzimetro Potentiometer power		Potentiometerspeisung Alimentation potentiomètre		Alimentación potenciómetro Alimentação do potenciómetro	
10V (J10 = ON, J15 = J24 = OFF)					



**Ingresso 0-10V**  
**0-10V Input**

Configurazione  
Ingresso sonda:

S3A (OFF)

Configuration  
Probe input:

S3B (OFF)

**Eingang 0-10V**  
**Entrée 0-10V**

Konfiguration  
Sensoreingang:

S3C (OFF)


Configuration  
Entrée capteur:

SI (OFF)

**Entrada 0-10V**  
**Entrada 0-10V**

Configuración  
Entrada sonda:


Configuração  
Entrada sonda:



**Moto-potenziometro**  
**Motopotentiometer**

**Motorpotentiometer**  
**Potentiomètre électronique**

**Moto-potenciómetro**  
**Moto-potenciômetro**




(\* )Set2 alternative to Set1

Schedina Comunicazione digitale  
Digital communication board

Digitale Datenaustausch karte  
Carte Communication numérique

Ficha Comunicación digital  
Placa Comunicação digital




**CONFIGURAZIONE HARDWARE  
HARDWARE CONFIGURATION  
HARDWARE-KONFIGURATION**

**CONFIGURATION HARDWARE  
CONFIGURACIÓN HARDWARE  
CONFIGURAÇÃO DO HARDWARE**

Scheda Alimentazione Lato Componenti  
Power board components side

NETZTEIL-KARTE BESTÜCKUNGSSEITE  
Carte ALIMENTATION CÔTÉ COMPOSANTS


Ficha de Alimentacion lado componentes  
Placa de ALIMENTAÇÃO lado dos componentes



Scheda CPU Lato Componenti  
CPU board components side

CPU-KARTE, BESTÜCKUNGSSEITE  
CARTE CPU CÔTÉ COMPOSANTS


FICHA CPU LADO COMPONENTES  
Placa CPU Lado dos componentes



Scheda CPU Lato Saldature  
CPU board solder side

CPU-KARTE, LÖTSEITE  
CARTE CPU CÔTÉ SOUDURES


FICHA CPU LADO SOLDURAS  
Placa CPU Lado das soldas



Scheda USCITA MAIN Lato Componenti  
MAIN OUTPUT board Components side

REGELAUSGANGSKARTE BESTÜCKUNGSSEITE  
CARTE SORTIE MAIN CÔTÉ COMPOSANTS

FICHA DE SALIDA MAIN LADO COMPONENTES  
Placa de saída MAIN lado dos componentes



Scheda USCITA MAIN Lato Saldature  
MAIN OUTPUT board Solder side

REGELAUSGANGSKARTE LÖTSEITE  
CARTE SORTIE MAIN CÔTÉ SOUDURES

FICHA DE SALIDA MAIN LADO SOLDADURAS  
Placa de saída MAIN lado das soldas

